











Troubleshooting Guide: Box Handle

SYMPTOM	PROBLEM		SOLUTION	
<p>Box does not stay attached to the Box Handle.</p> 	<p>Box wing nuts are not fastened securely to box handle connector plate</p>		<p>Tighten box wing nuts to connector plate on box handle.</p>	
<p>Extender Box Handle Brake will not hold Box.</p> 	<p>Brake set screw is not adjusted properly to brake hinge</p>		<p>Loosen lock nut and adjust set screw using a hex wrench. Tighten lock nut after completing the adjustment. Note: over tightening will make the brake drag.</p>	
	<p>Grip adjuster not properly set</p>		<p>Set grip adjuster to preferred setting, per user preference.</p>	
<p>Brake will not engage Box when using Box Extender Handle.</p> 	<p>Locking pin not engaged into profile extrusion-handle extension</p>		<p>Adjust locking pin to ensure that it is locked into profile extrusion-extension handle.</p>	