















Troubleshooting Guide: Mud Heads

SYMPTOM	PROBLEM	SOLUTION
<p>Mud Head is not putting enough joint compound onto the outside corner</p> 	<p>Joint compound mix is too heavy to flow evenly from the applicator thru the Mud Head</p> 	<p>Thin joint compound mix to similar consistency that you would use to finish internal corners with Corner Finisher and Corner Applicator or Mudrunner (Approximately 28 to 30 oz of water per 5 gallons of ready mixed joint compound).</p> 
	<p>Applicator not applying constant and immediate pressure when using the Mud Head with the Corner Applicator Tool</p> 	<p>Immediate and constant pressure is necessary when using the Corner Applicator with the Mud Head to achieve an even flow of joint compound onto the external corner.</p> 
	<p>Applicator does not have the control arm of the Mudrunner fully engaged to allow constant flow of joint compound from Mudrunner through the Mud Head</p> 	<p>Applicator needs to keep Mudrunner control arm fully engaged when applying joint compound to outside corners with Mud Head.</p> 
<p>Mud Head keeps flipping and coming off of the external corner</p> 	<p>Equal pressure not applied to Corner Applicator or Mudrunner when applying joint compound to external corner</p> 	<p>Apply equal pressure to Mud Head with the Corner Applicator or Mudrunner to maintain positive contact with external drywall corner. This will keep the Mud Head centered on the external corner as well as ensure good application of joint compound.</p> 
<p>Paper Faced Bead not seated properly to external corner</p> 	<p>External Corner Roller not used to embed paper faced bead to external corner</p> 	<p>Use Outside Corner Roller to embed and place paper faced bead product securely onto the external corner surface.</p> 